

ИНСТРУКЦИЯ К КОНДИЦИОНЕРУ

Кондиционер работает при вставленной карте в слот

ON/OFF

Для включения/выключения кондиционера
следует нажать на кнопку

MODE

выбор режима работы



Активное
охлаждение



Осушение



Приток
воздуха



Обогрев

FAN

Скорость вращения
вентилятора



Увеличение/уменьшение
температуры

TIMER

Включение
таймера

SWING/ENTER

Смена положения
жалюзи кондиционера

FUNCTION



Максимальная
мощность
за короткое время



Приток свежего
воздуха
без ионизации



Подсветка
табло



Ночной
режим

Важно! Когда Вы выбрали программу и комфортную
температуру, нажмите на кнопку SWING/ENTER

GLINZ

HOTEL

INSTRUCTIONS FOR THE AIR-CONDITIONER

The air conditioner works when the card is inserted into the slot

ON/OFF

To turn on / off the air conditioner,
press the button

MODE

selection of the operating mode



Active
cooling



Dehumidification



Air
supply



Heating

FAN

Fan speed



Temperature button:
increase/decrease

TIMER

Turn on
the timer

SWING/ENTER

Change the position of the
blinds of the air conditioner

FUNCTION



Maximum power
in a short time



The flow of fresh air
into the room without
ionization



Illumination
of a board



Night
mode

Important! When you have selected the program
and comfort temperature, press the SWING/ENTER button

